

1. Screw the tube (C) to the coupler (I) till tight.
2. Screw the tube (E1) to the tube (C) till tight.
3. Screw the tube (E2) to the tube (E1) till tight.
4. Screw the tube (E3) to the tube (E2) till tight.
5. Thread the nipple (F) to the tube (E3) till tight.
6. Hang the crystal drops (A) to the hook (G) on the pan. Hang the crystal drops (B) to the hook (H) on the pan. (Please refer to the drawing)
7. Install the G9 bulbs to the sockets (Bulbs is not included)

